

APPLICATION INSTRUCTIONS

EcoPrint



With its soft handle and soft surface, EcoPrint is a great alternative to printable flex films.





1. Print and cut





2. Weed design






3. Transfer, remove tape, done!

Printing profiles at www.seftextile.com Recommended transfer tape: FlockTape; connected designs can also be transferred without tape.

Drying time: Depending on ink and conditions 1 - 6h

For small designs, it can be useful to first apply the tape over the whole surface and then to weed it from the back.



Store in a cool and dry place; protect against the influence of light when stored. We recommend not to exceed a storage period of 36 months. The technical specifications rest on extensive tests and technical research. Due to the variety of possible influences during refinement, and use, the specifications should be viewed as reference values. We recommend a suitability test on the original material. A legally binding warranty of specific characteristics cannot be derived from our specifications.

